

-  PREMIUM COLLECTION
-  MEDIUM COLLECTION
-  LIGHT COLLECTION
-  WOBA KOLLEKTION

INSTALLATION

1. SUBSTRATE

Most solid substrates that are even clean and crack free, with a temperature of not less than 15 °C are suitable. The relevant standards i.e. BS 8203:2001 must be complied with. Where underfloor heating is installed the system must not exceed 28°C and it must be switched off for at least 48 hours prior to and following installation of the tiles.

2. INSTALLATION

To create the best layout, rooms should be divided and marked to facilitate a balanced distribution of tiles. The room temperature should be at least 18 °C, the relative humidity max. 75 %. The flooring must be acclimatized in the room to be floored for at least 24 hours before being put down. Likewise this temperature must be maintained up to 72 hours after the floor has been laid.

PROJECT FLOORS floor coverings must be glued into place with a dispersion adhesive using the wet gluing method. Recommended adhesive lists are available on request. Certain installation conditions (e.g. strong sunlight, high levels of moisture etc.) require specialist installation methods. Information can be found on our website, or alternatively from your technical sales consultant.

IMPORTANT:

Individual tiles/planks should not be tightly laid against one another, but should abut against one another with only gentle pressure! Immediately during and after laying, the flooring shall be rolled using an appropriate roller (at least 50 kg).

3. GENERAL INSTRUCTIONS

Uniformity of color of the goods is only guaranteed for deliveries of one production batch. Slight deviations cannot however be excluded. Damaged or faulty tiles/planks must be separated out prior to laying and returned with a complaint indicating the article and batch number. Office stools that are to be used on PROJECT FLOORS products must be fitted with soft type W castors according to DIN 68131.

(Stand 01.09.2012)

